

Project No: **BDHRN002**Job Card No **0025**

Notif.No.: 10049242

Activity: **1047**

Rev No: 20000622

Model.: F900EX

Sheet 1 of 1

A/C Regn: **D-AHRN**

Serial No.: 096

Type: F900EX

Starting Phase: Inspect

Starting Work Centre: FALCON A/C TEAM

Job Description: **GVI Portable Oxy Bottle & Masks (537wh)**

ETOPS A/C: No

RVSM A/C: No

Warranty: -

ATA: 35

Work Center	
FALCON A/C	

Zone: 200**Access Required for this task:**

PAX

Corrective Action

0001	Task carried out in accordance with the attached Customer Card that quotes the Operator code detailed below.					 Order: 80069319 Operation: 0010 Phase: Inspect - scheduling activity Work Center: FALCON A/C TEAM
	Accomplished		Inspected			
	Pers. No.	Date	Pers. No.	Date		
	Stamp		Stamp			

Completed & Confirmed on SAP IAW MOE 2.13.

Defect Card Raised

Components Removed/Installed

	Part Number	Part Name	S/N	Location	Comm. Off/On
OFF					
ON					
OFF					
ON					
OFF					
ON					
OFF					
ON					

Occurance Report Raised? YES ☐

Operations Above & Notifications Completed IAW MOE 2.13.

OEM Code: 35-30-05-210-801-01

Operator Code: 35-30-05-210-801-01

Form No: JA-SAP-MTX-002

Printed by: ADAMOVIC G



Printed: 03.09.2012

13:34:17

Print No: 1

Operator: **HERON AVIATION**

Work Card No.: **35.220**

Serial No.: **096**

Model: **FALCON 900EX**

Reg No.: **D-AHRN**

Workorder No.: _____

	Date	A/C HRS	AFL	APH			
Due At	18-JAN-2013						
Accomplished							

TECHNICIAN SIGNATURE: _____ KIND OF CERTIFICATE & NO.: _____

INSPECTED BY: _____ KIND OF CERTIFICATE & NO.: _____

TECH	INSP	LABOR-HRS HRS.MINS
------	------	-----------------------

**>35-30-05-210-801- GENERAL VISUAL INSPECTION PORTABLE OXYGEN CYLINDER
01 (INCLUDING MASK)**

REMARKS : _____

AMM 35-30-05-210-801

Operator: **HERON AVIATION**

Work Card No.: **35.220**

Serial No.: **096**

Model: **FALCON 900EX**

Reg No.: **D-AHRN**

Workorder No.: _____

SOURCE SUMMARIES

956 MPD 05-20-35 PAGE NO.:PAGE 2/3 REF: 35-30 PORTABLE OXYGEN SYSTEM DATE: JUN 10/2011 1

35-30-05-210-801-01 GENERAL VISUAL INSPECTION PORTABLE OXYGEN CYLINDER (INCLUDING MASK)

956 MPD 05-20-35 PAGE NO.:PAGE 2 / 3 REF: 35-30 PORTABLE OXYGEN SYSTEM DATE: JUN 10/2011 1

35-30-05-210-801-01 GENERAL VISUAL INSPECTION PORTABLE OXYGEN CYLINDER (INCLUDING MASK)

FALCON 900EX AIRCRAFT MAINTENANCE MANUAL

TASK 35-30-05-210-801

GENERAL VISUAL INSPECTION OF THE PORTABLE OXYGEN BOTTLE

1. OVERVIEW OF THE JOB

Operation code: 35-30-05-210-801-01 portable oxygen bottle and masks (537WH)

NOTE: Refer to the Supplemental Maintenance Manual (SMM) for the portable oxygen bottle location (one or more portable oxygen bottles may be installed, depending on aircraft completion).

2. LOGISTICS

A. References

Reference

• [35-30-09-100-801](#)

Designation

CLEANING OF THE PORTABLE OXYGEN MASKS

B. Ingredients and Consumable Products

Designation

• [LEAK DETECTOR](#)

Additional designation

C. Access

Reference

• [PAX](#)

Designation

PASSENGER DOOR

D. Miscellaneous

• LINT-FREE CLOTH

3. VISUAL INSPECTION

A. Clean the portable oxygen bottle masks (Refer to [TASK 35-30-09-100-801](#)).

B. Perform a visual inspection of the portable oxygen bottle for:

- corrosion,
- bulges,
- gouges,
- distorsion,
- attachment fittings.

C. If one of the above defects is found, return the portable oxygen bottle to an approved repair agent.

D. Perform a check of the current hydrostatic test date.

E. If the expiry date is overdue, return the portable oxygen bottle to an approved repair agent.

F. Make sure there are no leaks at the couplings of the portable oxygen bottle with [leak detector](#).

G. If there is a leak, return the portable oxygen bottle to an approved repair agent.



FALCON 900EX AIRCRAFT MAINTENANCE MANUAL

H. Wipe off with a lint-free cloth.