

Project No: **BDHRN002**Job Card No **0057**

Notif.No.: 10049243

Activity: **1048**

Rev No: 20000622

Model.: F900EX

Sheet 1 of 1

A/C Regn: **D-AHRN**

Serial No.: 096

Type: F900EX

Starting Phase: Routine

Starting Work Centre: FALCON A/C TEAM

Job Description: **CLN Portable Oxy Bottle & Masks 537wh**

ETOPS A/C: No

RVSM A/C: No

Warranty: -

ATA: 35

Work Center	
FALCON A/C	

Zone: 200**Access Required for this task:**

PAX

Corrective Action

0001	Task carried out in accordance with the attached Customer Card that quotes the Operator code detailed below.					 Order: 80069320 Operation: 0010 Phase: Routine - scheduling activity Work Center: FALCON A/C TEAM
	Accomplished		Inspected			
	Pers. No.	Date	Pers. No.	Date		
	Stamp		Stamp			

Completed & Confirmed on SAP IAW MOE 2.13.

Defect Card Raised

Components Removed/Installed

	Part Number	Part Name	S/N	Location	Comm. Off/On
OFF					
ON					
OFF					
ON					
OFF					
ON					
OFF					
ON					

Occurance Report Raised? YES ☐

Operations Above & Notifications Completed IAW MOE 2.13.

OEM Code: 35-30-09-100-801-01

Operator Code: 35-30-09-100-801-01

Form No: JA-SAP-MTX-002

Printed by: ADAMOVIC G



Printed: 03.09.2012

13:34:17

Print No: 1

Operator: **HERON AVIATION**

Work Card No.: **35.220**

Serial No.: **096**

Model: **FALCON 900EX**

Reg No.: **D-AHRN**

Workorder No.: _____

	Date	A/C HRS	AFL	APH			
Due At	18-JAN-2013						
Accomplished							

TECHNICIAN SIGNATURE: _____ KIND OF CERTIFICATE & NO.: _____

INSPECTED BY: _____ KIND OF CERTIFICATE & NO.: _____

TECH	INSP	LABOR-HRS HRS.MINS
------	------	-----------------------

**>35-30-09-100-801- CLEANING PORTABLE OXYGEN CYLINDER MASKS
01**

REMARKS : _____

AMM 35-30-09-100-801

Operator: **HERON AVIATION**

Work Card No.: **35.220**

Serial No.: **096**

Model: **FALCON 900EX**

Reg No.: **D-AHRN**

Workorder No.: _____

SOURCE SUMMARIES

956 MPD 05-20-35 PAGE NO.:PAGE 2/3 REF: 35-30 PORTABLE OXYGEN SYSTEM DATE: JUN 10/2011 1

35-30-09-100-801-01 CLEANING PORTABLE OXYGEN CYLINDER MASKS

956 MPD 05-20-35 PAGE NO.:PAGE 2 / 3 REF: 35-30 PORTABLE OXYGEN SYSTEM DATE: JUN 10/2011 1

35-30-09-100-801-01 CLEANING PORTABLE OXYGEN CYLINDER MASKS

FALCON 900EX AIRCRAFT MAINTENANCE MANUAL

TASK 35-30-09-100-801 CLEANING OF THE PORTABLE OXYGEN MASKS

1. OVERVIEW OF THE JOB

Operation code: 35-30-09-100-801-01 portable oxygen bottle and masks (**537WH**)

NOTE: Refer to the Supplemental Maintenance Manual (SMM) for the portable oxygen bottle and masks (**537WH**) location.

2. LOGISTICS

A. Ingredients and Consumable Products

Designation

- **OXYGEN MASK CLEANER**
- **DISINFECTANT**

Additional designation

OXYGEN

B. Access

Reference

- **PAX**

Designation

PASSENGER DOOR

C. Miscellaneous

- SOFT BRISTLE BRUSH
- TOWELLING
- SPONGE
- LINT-FREE CLOTH

3. CLEANING

- Clean the portable oxygen bottle mask with **oxygen mask cleaner** using a soft bristle brush or towelling.
- Rinse the portable oxygen bottle mask with pure water (sponge or cloth moistened with water).
- Wipe off with a lint-free cloth.
- Allow to dry in ambient air.
- Spray **disinfectant** on inner surfaces.

Effectivity: A/C WITH PORTABLE OXYGEN BOTTLE

Rev. Date: MAR 09/2012

35-30-09-100-801

page 1 / 1